

OPEX[™] FALCON[®]+

One-Touch Scanning Designed to Minimize Prep



WHY FALCON[®]+SCANNER?

The only high-volume scanner you can purchase that can significantly reduce, costly prep time.

The Falcon[®]+scanner processes payments and scans documents of nearly any size, thickness, or condition directly from file folders, producing images and usable data in mere milliseconds, with virtually no document prep work. Feed damaged, fragile, and small documents such as torn papers and receipts directly into the feeder. Documents are handled only once, significantly reducing labor costs while increasing document security and integrity.

FEATURES

UNIVERSAL DOCUMENT FEEDER

The Falcon+ feeder reduces the need to prepare documents prior to scanning. Its ability to handle mixed sizes, types, and paper weights enables documents to be fed as single pages or in stacks.

ENHANCED MULTI-FEED DETECT

Seven strategically placed Ultrasonic Multi-Feed Detectors (MFDs) recognize double feeds, sticky notes, and turned corners anywhere on a page and notifies the operator, helping produce the most accurate scanning results in the market.

CERTAINSCAN[®] SOFTWARE

OPEX[®] CertainScan[®] builds customized scanning jobs, identifies page types within a job, and automates many traditional document prep activities all while integrating with your software.

THICKNESS MEASURING DEVICE (TMD)

The Thickness Measuring Device (TMD) will automatically detect and classify envelopes as transaction separators. Thus, doing away with the expensive and time-consuming task of inserting traditional separators.

ADVANTAGES

EFFICIENCY AND FLEXIBILITY

The Falcon+ can easily process anything from thick paper to onion skin to pristine or damaged pieces, without pre-sorting. It can process envelopes and file folders, receipts, and other small documents without taping or copying. It can even handle X-rays and three-dimensional objects with ease.

ONE-TOUCH SCANNING

Falcon+ document scanners minimize virtually all prep, paper handling, and manual tasks to ensure a safe, fast, and accurate document transformation process. Touch the paper once between the folder and the transformation to image.

ENHANCED SORTING CAPABILITIES

Available in configurations of three or five programmable sort-bins, the Falcon+ provides versatile and unique sorting abilities. With expanded bin capacity and waterfaling, the Falcon+ allows for a nearly unlimited batch size. All Falcon+ models are equipped with an additional pass-through bin, ideal for thick and delicate items.

SUPERIOR SECURITY AND DOCUMENT INTEGRITY

In today's world of heightened data security and compliance, One-Touch Scanning helps ensure efficient, safe and secure document transformation that makes sense, guarding against costly data breaches.

SPECIFICATIONS

PHYSICAL DIMENSIONS (HXWxD)

Falcon+[®] 64.35" x 102" x 32.27" (163.45cm x 259.1cm x 81.97cm)

FalconV+[®] 71.4" x 102" x 32.5" (181.4 cm x 259.1 cm x 82.5cm)

ADDITIONAL SPECIFICATIONS

Scanning Speed Up to 120 ppm (letter)/115 ppm (A4) @ 300 dpi

In-line Recognition OCR, OMR, barcodes, document type ID

Document Feeding Continuous drop feed, packet feed, rescan feed

Daily Duty Cycle Unlimited

Media Detection Multi-feed detection, height, length, skew and envelope detection

Bundled Software CertainScan[®] 64 bit host software, CertainScan[®] Edit[™], CertainScan[®] Transform[™], OPEX[®] standard barcode package, Windows 11 64 bit

DOCUMENT DIMENSIONS

Length 3.5"-100" (8.89-254 cm)

Width 2.0"-12" (5.08-30.48 cm)

STANDARD FEATURES

- Automatic page classification
- Automatic de-skew
- 7 Ultrasonic Multi-Feed Detectors
- 600 dpi capture
- Thick document sorting
- 3 or 5 programmable sort bins
- Mixed document capture
- 22" touch-screen display
- Wireless keyboard/mouse
- Packet-sensing technology
- Early envelope detect
- ID Assist
- Reference ID
- Top Bin Mirror
- TMD override


OPTIONAL FEATURES

- FADGI 3-Star Capable
- Modern Textual Records
- External digital capture
- MICR/MICR+ (US Only)
- Mobile Work Surface
- 1D and 2D Barcodes
- ScanLink API
- VRS[®] Technology*
- ProcessLink
- Key Assist[™]
- Bankers Box Cart
- MultiAssist Tower
- Audit trail printing (front & rear)
- Rear graphics printer for signature and code 39 & 128 barcode printing
- CertainScan[®] Edit[™] and CertainScan[®] Transform[™] on external PC

*VRS is a registered trademark of Kofax, Inc.

Have questions?
Contact us.

 opex.com

 info@opex.com

OPEX[®]