

OPEX[®] FALCON⁺ RED[™]

Mail Opening & Scanning Designed to Minimize Prep



WHY FALCON⁺ RED[™]?

Easily handle peak mail volumes and labor challenges with the OPEX[®] Falcon⁺ RED[™] document scanner with integrated mail opening and extracting capabilities. Using the Falcon+ RED, mailroom operations process incoming mail as soon as it is received, directly out of the envelope. Open a variety of envelope types and scan a wide range of document sizes, thicknesses, or conditions while producing high-quality images and usable data in seconds. Only requiring one operator per system, the Falcon+ RED mail scanning platform minimizes prep work, pre-sorting, and manual processes, resulting in reduced labor costs and improved productivity. It provides one of the fastest ROIs on the market.

FEATURES

UNIVERSAL DOCUMENT FEEDER

The Falcon+ feeder reduces the need to prepare documents prior to scanning, and enables documents to be fed as both single pages or in stacks of intermixed weights and sizes.

INTEGRATED MAIL OPENING AND EXTRACTION

The Falcon+ Scanner easily integrates with the Rapid Extraction Desk (RED) for easy mail opening, extraction, and scanning on a single platform. Open a wide variety of envelopes and feed the contents directly into the scanner to create high-quality images.

CERTAINSCAN[®] SOFTWARE

OPEX CertainScan[®] allows for customized scanning jobs, identifies page types within a job, and automates many traditional document prep activities - all while integrating with your existing software.

ENHANCED MULTI-FEED DETECT

Seven strategically placed Ultrasonic Multi-Feed Detectors (MFDs) recognize double feeds, sticky notes, and turned corners anywhere on a page and notifies the operator, helping produce the most accurate scanning results in the market.

ADVANTAGES

EFFICIENCY AND FLEXIBILITY

The Falcon+ RED scanner can easily process anything from thick paper to onion skin to fragile or damaged pieces, without pre-sorting. It can process envelopes and file folders, receipts, and other small pages without taping or copying. It can even handle X-rays and three-dimensional objects with ease.

ONE-TOUCH SCANNING

Falcon+ RED document scanners minimize virtually all prep, paper handling, and manual tasks to ensure a safe, fast, and accurate document transformation process.

ENHANCED SORTING CAPABILITIES

Available in configurations of three or five programmable sort-bins, the Falcon+ RED provides versatile and unique sorting abilities. With expanded bin capacity, the Falcon+ RED allows for a nearly unlimited batch size. All Falcon+ RED models are equipped with an additional pass-through bin, ideal for thick and delicate items.

SUPERIOR SECURITY AND DOCUMENT INTEGRITY

In today's world of heightened data security and compliance, One-Touch Scanning ensures efficient, safe, and secure document transformation that makes sense, guarding against costly data breaches.

OPEX[®] FALCON⁺ RED[™]

SPECIFICATIONS

PHYSICAL DIMENSIONS (HxWxD)

Falcon+ RED	55" x 111.10" x 41.60" (139.7 cm x 282.194 cm x 105.66 cm)
-------------	--

FalconV+ RED	61.60" x 111.10" x 42" (156.46 cm x 282.2 cm x 106.7 cm)
--------------	--

ADDITIONAL SPECIFICATIONS

Scanning Speed	Up to 120 ppm (letter)/115 ppm (A4) @ 300 dpi
----------------	---

In-line Recognition	OCR, OMR, barcodes, document type ID
---------------------	--------------------------------------

Document Feeding	High-capacity auto feed, continuous drop feed, packet feed, rescan feed
------------------	---

Daily Duty Cycle	Unlimited
------------------	-----------

Media Detection	Multi-feed detection, height, length, skew and envelope detection
-----------------	---

Bundled Software	CertainScan [®] 64 bit host software, CertainScan [®] Edit [™] , CertainScan [®] Transform [™] , OPEX standard barcode package, Windows 10 64 bit
------------------	--

DOCUMENT DIMENSIONS

Length	3.5"-25.50" (8.89-64.77 cm)
--------	-----------------------------

Width	2.0"-12" (5.08-30.48 cm)
-------	--------------------------

STANDARD FEATURES

- Automatic page classification
- Automatic de-skew
- 7 Ultrasonic Multi-Feed Detectors
- 600 dpi capture
- Thick document sorting
- 3 or 5 programmable sort bins
- Mixed document capture
- 22" touch-screen display
- Wireless keyboard/mouse
- Packet-sensing technology
- Early envelope detect
- Multi-Function ID Assist[™]
- Reference ID
- Top Bin Mirror
- TMD override


OPTIONAL FEATURES

- FADGI 3-Star Capable
- External digital capture
- MICR/MICR+ (US Only)
- Mobile Work Surface
- 1D and 2D Barcodes
- ScanLink API
- VRS[®] Technology*
- Key Assist[™]
- Bankers Box Cart
- Audit trail printing (front & rear)
- Rear graphics printer for signature and code 39 barcode printing
- CertainScan[®] Edit[™] and CertainScan[®] Transform[™] on external PC

*VRS is a registered trademark of Kofax, Inc.

Have questions?
Contact us.

 opex.com

 info@opex.com

OPEX[®]